



PEDESTAL USER INSTALLATION GUIDE



PEDESTAL USER INSTALLATION GUIDE

Manufacturer Supplied Components:

1. Pedestal secure cabinet
2. Dell small form factor PC
3. Weather-resistant keypad
4. Weather resistant electronic display
5. Thermal receipt printer
6. Power strip
7. FCC Required Safety and Regulatory Documentation

OVERVIEW

Each new Pedestal is shipped with the *Manufacturer Supplied Components* listed above. For best results, read and become familiar with the product documentation included as well as the product components included with the installation shipment.

INSTALL GUIDE

The Pedestal will be shipped fully assembled. All electronic components and peripherals will be connected to the unit. User installation entails mounting the cabinet, and connecting power and network.

*Be sure to utilize a licensed electrician when installing a junction box at the pedestal site.

FINAL ASSEMBLY AND INSTALLATION INSTRUCTIONS

1. Prior to Pedestal delivery, an electrician must run a junction box with an outlet and a network connection to the Pedestal site.



2. Open the bottom cabinet.



3. Plug your Ethernet cable into the port at the top of the cabinet. Ensure the power cable from the power strip is fed through the port from the top cabinet.



4. Mount the Pedestal to its permanent location via the mounting holes at the base of the cabinet.




5. Open the top cabinet and verify all components are connected to the power strip and the CPU.



6. Both the keypad and the card reader utilize complex connectors.



7. Connect the Ethernet cable to your network. Plug in the power cable for the pedestal and ensure the power strip rocker switch is in the 'on' position. Your Pedestal will power up.



Power Strip

