

## **Pioneer Installation Configuration**

\*Plug in equipment upon receipt to verify functionality.\*



#### VeriFone Adapter



Serial to 3rd party POS Auxiliary Network Port

Black Ethernet cable from VeriFone Adapter to POS (only applicable to VeriFone POS applications)

### **3rd Party Point of Sale**

Ruby/Sapphire, Pinnacle, Palm, Radiant, etc.

#### **Network Switch**



(Not supplied by Triple E)

#### Pioneer

Ethernet cable (not supplied by Triple E) from Modem/Router to Pioneer



Monitor and keyboard (not supplied) required for training

# 9-Pin Omni Cable to COM1 on Pioneer (RJ45 side to Pilot)



#### **Pilot Terminal**



(Optional Equipment)